



THE BRIGHTEST IDEAS IN WHITEBOARDS

Everase Write-a-Wall Erasable Wallcovering **Suggested Installation Instructions**

Preparation of Goods: Examine goods to assure that color uniformity, quality and gloss level are as ordered. Separate goods by roll numbers to apply in sequential order. Unroll the material to the length of the wall to be installed plus 6" each edge, re-roll the material as it was originally shipped to you using a large loop about 12" diameter. (surface inside)

Preparation of Wall Surfaces: Proper wall prep requires that all wall surfaces to be installed must be clean, smooth, dry, uniform in color, structurally sound and free of mold, mildew, grease or stains. To ensure good adhesion, any old wallcovering and/or loose paint flakes must be removed. To ensure a smooth wall surface, imperfections, such as nail heads and gouges, should be filled with joint compound, allowed to dry and then sanded smooth. If the wall surface has any grease stain, wash with a solution of diluted ammonia, rinse and allow to dry. It is recommended to only use lead pencils to mark the back of wallcovering or wall surfaces. Do not hang wallcovering over ballpoint ink, wax crayon, oil-based stains or any foreign matter that could bleed through to the face of the wallcovering.

Moisture Accumulation: Some buildings, particularly in warm, humid climates, can have moisture infiltration problems which can lead to mold and mildew growth. Any such problem must be corrected prior to the installation of wall covering. This product is only intended for use in building that are properly designed and maintained to avoid moisture infiltration and/or condensation within the wall cavities. If any mold/mildew is present or if the walls show signs of visible moisture damage, do not proceed with the installation until the condition has been fully corrected under the direction of a qualified expert. For proper installation and product performance, walls to be installed should be checked with a reliable moisture meter. Moisture content shall not exceed 4%.

Adhesives: Sand smooth any nipping or brush stroke marks. Clear wall covering adhesive (Roman PRO-555 Extreme Tack- Sherwin Williams) full-strength; do not dilute. Adhesive should be stored at room temperature of at least 55° F (13° C) with a relative humidity of 40% or less. The room being installed should also maintain this temperature and humidity level 72 hours before, during and after the install.





THE BRIGHTEST IDEAS IN WHITEBOARDS

Application: When installing vertical strips, use a plumb line. When installing the material horizontally use a level line. If hanging horizontally, be mindful of where the seams will fall. Your prime writing area will be 36" above the floor line.

Before cutting the material, make certain the color and gloss level are satisfactory as specified.

Cut strips a few inches (2 to 3") longer than required to allow for trimming at ceiling line or baseboards. Cut all headers above doors and windows as you come to them.

Apply an even coat of clear adhesive (PRO- 880 Ultra clear strippable) to the wall using a low nap roller. Use the pre-cut strips carefully align the edges to prevent adhesive from getting on to the surface edges. Use caution not to crease the wall covering when applying.

Install the first strip aligned to the penciled plumb or level lines by using a low nap roller or soft rubber roller to remove air pockets from behind the material. Smooth material on the wall working from the middle out towards the edges. Some of the adhesive will escape from the edges use warm water to clean rag to remove, but don't push out too much.

The next strip of wall covering must butt the seam as tight as possible. Use the small hard roller against the seam. Trim material with a razor (change blades often) at ceiling, baseboard, doors and windows as you come to them. Use caution not to score the paper of the wall surface below. Clean each seam with a natural sponge and clean warm water as you come to them. Rinse thoroughly with warm water and dry with a clean towel.

However after this third strip is secured and trimmed in place, STOP, step back and carefully inspect the workmanship and outcome. Look for bubbles excess adhesive at seam or edges. If you have any questions or concern about the quality of how this product is installing, stop working and notify your supplier immediately. Your decision to continue installing after this third strip conveys your acceptance of the materials.

Vertical joints should not be present within 6" from an inside or outside corner. Never use an abrasive cleaner on this writing surface. Our standard, high gloss material is dry-erasable.

Our matte, low gloss material is wet-erasable, which requires a whiteboard cleaner. Some customers may prefer the low gloss version when the surface is being used as a projection screen.

5-22-19